



tabulka použití



AVIA	☺	☾
1000, 1250, 1601, 1602, 2000	510	510
3601, 3602, 5601, 5603	510	510
F260, F275	510	510
AYATS	☺	☾
Bravo I ▼	1000	1000
BERKHOF	☺	☾
Ambassador 120 / 200 (Vdl) (00-)	1000	1000
Axial 100 ▲ (99-)	660	660
Axial 70 ▲ (94-)	660	660
Clubbus (Volvo)	1000	1000
Excellence 2000 HL ▼	800	800
Excellence 3000 HLE / HD ▼	800	800
BEULAS	☺	☾
Aura	1000	1000
BOVA	☺	☾
EL 24-480	800	800
EL 24-581, EL 26-581	800	800
EL 24-605, EL 26-605	800	800
MB 0614	600	600
CAETANO	☺	☾
City Gold (96-)	700	700
Optimo (96-)	800	800
CASTROSUA	☺	☾
CS 40 City / Bus urbain (86-)	700	700
CS 40 Inter City / Bus urbain (86-)	800	800
Master 36 (96-)	1000	1000
CITROËN	☺	☾
Berlingo 1 (01/97-10/02)	550	550
Berlingo 1 (11/02-04/08)	550	550
C25 (12/81-02/94)	510	510
C32 (12/81-02/94)	510	510
C35 (11/73-12/91)	510	510
Dispatch (10/95-12/06)	660	510
Jumpy (10/95-12/06)	660	510
DAF	☺	☾
CF 65, CF 75, CF 85 (03/98-)	600	600
F 1600 - F 3600 (01/73-92)	510	510
F 500, F 700, F 900, F 1100, F 1300, F 1500 (01/75-92)	600	600
F 55 (01/93-01)	510	510
F 65 (01/93-98)	600	600
F 75 (01/92-98)	600	600
F 85 (01/92-98)	600	600
F 95 (06/91-02/97)	550	550
N 2800 - N 3300 (01/79-12/86)	600	600
XF 105 (03/06-)	550	550
XF 95 (03/97-)	550	550
DRÖGMÖLLER	☺	☾
E 420, E 440 ▼	800	800
E 420, E 440 ▲	700	700
E 430 ▼ (01/89-)	660	660
E 430 ▲ (01/89-)	700	700
ERF	☺	☾
CP Turbo	510	510
E (01/86-)	510	510
E 10	510	510
EC 11, 12, 41	600	600
ECX	600	600
ERNST AUWÄRTER	☺	☾
B 13/42/1	800	800
Clubstar (813/42-1, 913/48)	800	800
Clubstar (Man 14 280) (03-)	1000	1000
Clubstar (Mb1223 Atego)	1000	1000
Eurostar (SHD 0 404) (96-)	1000	1000
Panorama (MB 818) (03-)	1000	1000
Super Sprinter (MB 416 /616) (-06/06)	600	550
Teamstar (613/41, L613 D)	800	800
Teamstar City MB 818 D Vario (96-)	1000	1000
Teamstar MB 0815	1000	1000
FAHR	☺	☾
M 1002, M 1102, M 1202 (-01/76)	510	510
M 750, M 900, M 922 (01/74-)	510	510
FIAT	☺	☾
Ducato (05/81-04/94)	510	510
Scudo (10/95-)	660	510
Talento (01/89-94)	510	510
FORD	☺	☾
Cargo (01/75-01/85)	600	600
Cargo (02/85-)	660	660
Tourneo Connect (01/03-03/04)	550	550
Transit 2000 (11/00-)	600	600
Transit Connect (01/03-03/04)	550	550

GINAF	☺	☾
C 2120 N- (08-)	660	660
M 1312, 3333, 4243, 4443	600	600
X 2221	600	600
X 3232, 3329, 3331, 3335	600	600
X 4241, 4243, 4343, 4345, 4446	600	600
X 5250, 5350, 5450	600	600
IKARUS	☺	☾
397.07 ▲ (01/93-)	800	800
Midibus 405	800	800
Minibus 542, 546 (86-)	600	600
Stadtbus 480 (01/92-)	700	700
INDCAR	☺	☾
Mago	800	800
IRISBUS	☺	☾
370 (Iveco) (-08/82)	800	800
470.67 (Iveco) (81-)	800	800
570 (Iveco) (81-)	800	800
670 (Iveco) (81-)	800	800
Axer (Renault)	800	800
Cityclass (Iveco) (95-)	1000	1000
GX 117 Access' Bus (Heuliez)	800	800
GX 217 Access' Bus (Heuliez)	800	800
GX 27 (Heuliez) (12/88-)	700	700
GX 317 Access' Bus (Heuliez)	800	800
GX 37 (Heuliez) (12/88-)	700	700
GX 417 Access' Bus (Heuliez)	800	800
M 120 R 81 Turbo (Iveco) (81-)	800	800
My Way (Iveco) (06/98-)	1000	1000
Orlandi 315S.8.18 (Iveco) (01/92-)	800	800
PR 100, PR 180 (Renault) (08/83-)	700	700
S 45, S 53, S 105 (Renault) (06/80-)	600	600
SC 10 (Renault) (02/77-)	700	700
SG 220 (Renault) (02/77-)	700	700
ISUZU	☺	☾
NKR (01/97-)	510	510
NPR (01/97-)	510	510
IVECO	☺	☾
242 (01/80-01/82)	510	510
280 (01/81-)	510	510
370 (-08/82)	800	800
109.14 Zeta (09/88-)	510	510
135.17, 145.17T (09/88-)	600	600
190.20 N (07/80-12/85)	600	600
190.20 N (07/80-12/85)	600	600
190.25 AH (07/83-06/86)	660	660
190.25 AN (07/83-09/90)	600	600
190.26 (01/83-01/84)	660	660
190.26 N (01/83-06/87)	600	600
190.30 H, P (07/80-)	660	660
190.30 N (04/87-)	600	600
190.32 GV, P (07/87-)	660	660
190.33 P (07/84-05/87)	660	660
190.35 (01/83-01/84)	660	660
190.36 P, T (07/87-)	660	660
190.38 P (07/80-12/87)	660	660
190.38 PT (07/84-)	660	660
190.42 P (07/84-)	660	660
190.48 P (07/84-)	660	660
220.30 PT (07/80-07/86)	660	660
220.32, P, PT, 220.36, P, PT (-07/87)	660	660
220.38 PT (07/80-07/86)	660	660
232.32 AHT (01/83-)	600	600
260 SH 170 (VÖV) (01/81-)	700	700
260.25 AN (07/83-06/86)	600	600
260.26 H (-07/83)	660	660
260.26 NW (01/77-01/86)	600	600
260.32 (07/90-)	660	660
260.35 H (01/83-12/83)	660	660
260.36 (07/88-)	660	660
260.48 (06/89-)	660	660
300 PC, PT (01/77-07/88)	660	660
320 M (01/79-)	600	600
320.30 H (01/84-)	660	660
320.31 ANW (07/80-12/83)	600	600
330.25 AN (05/89-)	600	600
330.26 P (01/83-01/84)	660	660
330.30 AH (05/86-05/91)	660	660
330.30 AN (05/86-09/90)	660	660
330.30 AN (05/86-09/90)	600	600
330.30 H (06/84-)	660	660
330.30 N (10/87-)	600	600
330.32 ANW (07/83-06/87)	600	600
330.32 ANW (07/83-06/87)	660	660
330.35 P (07/80-01/92)	660	660
330.36 H, HW (01/89-)	660	660
79.14 M100 (01/83-)	600	600
80.13 (01/83-)	600	600

pokračování →

IVECO	☺	☾	☺	☾
Autodromo, Dow Town (01/94-)	800	800		
Daily, Turbo Daily (01/80-05/99)	600	600		
EuroCargo (01/92-)	660	660		
EuroFire	660	660		
EuroStar (01/94-02)	660	660		
EuroTech (01/92-00)	660	660		
EuroTrakker (01/94-)	660	660		
M 100 (01/83-)	600	600		
NKW 80.13, 80.16 (01/82-)	600	600		
Powerstar	660	660		
Stralis (39449)	660	660		
Stralis (02/08-)	660	660		
Trakker (39449)	660	660		
Trakker (02/08-)	660	660		
Turbostar 180.24 - 330.36 (01/77-93)	660	660		
Turbotech 13.16, 65.10, 75.16 (01/83-9600)	600	600		
Turbotech 180.24 - 330.36 (01/77-93)	660	660		
Turbotech 19-30, 19-38 (01/81-)	600	600		
JELCZ	☺	☾	☺	☾
Jelcz O 80 (01/80-)	600	600		
JONCKHEERE	☺	☾	☺	☾
Auteuil (01/92-)	800	800		
Jubilee P35, P90, P599	700	700		
Le Deauville ▼ (10/91-)	800	800		
Le Deauville ▲ (10/91-)	600	600		
Mistral 50	1000	1000		
Mistral 70 ▼ (99-)	1000	1000		
Monaco ▼	800	800		
KAROSA	☺	☾	☺	☾
Recreo (97-)	800	800		
KÄSSBOHRER-SETRA	☺	☾	☺	☾
Pistenbully PB 36.170 D (11/81-)	660	660		
Pistenbully PB 39.170 DR (11/81-)	660	660		
Pistenbully PB 42.240 D (88-)	800	800		
S 208 A (10/80-)	800	800		
S 213 HE (87-)	800	800		
S 309 HD (07/91-)	1000	1000		
S 312 HD (07/91-)	1000	1000		
S 315 GT (09/94)	1000	1000		
S 315 GT-HD (09/96-)	1000	1000		
S 315 HD (07/91-)	1000	1000		
S 315 HDH ▼ (07/91-)	1000	1000		
S 315 NF (07/91-)	1000	1000		
S 315 UL (09/94-)	1000	1000		
S 317 GT-HD (11/99-)	1000	1000		
S 319 GT-HD (12/98-)	1000	1000		
S 319 NF (12/97-)	1000	1000		
S 319 UL (07/91-)	1000	1000		
S 411 HD (01-)	1000	1000		
S 416 ▲ (01-)	600	600		
SG 321 UL (08/95-)	1000	1000		
LEYLAND / DAF	☺	☾	☺	☾
LDV Convoy (09/96-)	510	510		
LDV Maxus (07-)	510	510		
MAN	☺	☾	☺	☾
17.240 - 32.321 (08/82-88)	510	510		
D 80, G 80, S 80	800	800		
F 2000 (19.343 - 48.463) (10/94-)	600	600		
F 90 (19.242 - 48.462) (01/86-09/94)	600	600		
FE 600A, FE 460A	600	600		
FRH 402 (Lion's Star) (93-04)	1000	1000		
FRH 422 (Lion's Star) (93-04)	1000	1000		
G 90 (4.70 - 9.136) (11/79-12/94)	510	510		
L 2000 (8.103 - 10.223) (01/94-)	510	510		
M 2000 L (cab. L, 12-19L) (04/96-10/05)	510	510		
M 2000 M (cab. F, 12-19L) (04/96-10/05)	600	600		
M 90 (12.152 - 18.232) (01/86-12/96)	600	600		
MN 283 (Lion's Midl)	800	800		
NG 272 (89-)	800	800		
NG 312	800	800		
NG 313	900	900		
NL 202 (09/89-)	800	800		
NL 222	800	800		
NL 223 (99-)	900	900		
NL 232	800	800		
NL 262	800	800		
NL 263	900	900		
NL 312	800	800		
NL 313 Lion's City	900	900		
NL 353 (99-)	900	900		
NM 152 (89-97)	800	800		
NU 263 (09/96-)	1000	1000		
NU 313	900	900		
RH 403 (Lion's Star)	1000	1000		
RH 463 (Lion's Star) (92-04)	1000	1000		

pokračování →

MAN	☺	☾	☺	☾
RN313/353/R353 (Lion's Comf.) (09/96-)	1000	1000		
SD 200 (10/78-11/86)	700	700		
SD 202 (08/85-94)	800	800		
SG 220/240 H, HU (05/80-01/86)	700	700		
SG 240 H (08/85-)	800	800		
SG 242/SG 242 H (85-94)	800	800		
SG 292 (85-)	800	800		
SL 200 (08/85-87)	800	800		
SL 200 (10/78-04/87)	700	700		
SL 202 (06/84-94)	800	800		
SR 240/280/321/361 (10/75-11/86)	700	700		
SU 240 (10/75-84)	700	700		
SU 240 (85-89)	800	800		
SU 242 (85-87)	800	800		
SU 310 (99-)	900	900		
TG	700	700		
TGA (09/04-)	700	700		
TGL (cab. C / L / LX) (05/05-)	700	700		
TGM (cab. C / L / LX) (11/05-)	700	700		



tabulka použití



MITSUBISHI	☞	☞
Canter 3S11, 3S13, 5S13 (97-)	510	510
L 200 (10/96-02/06)	510	510
NEOPLAN	☞	☞
Centroliner N4407	800	800
Centroliner N4411 / N4426 --	900	900
Centroliner N4416 / 4416 U (99-)	800	800
Cityliner N1116-▼	700	700
Cityliner N1116-▲	800	800
Cityliner N116 ▼ (09/00-)	1000	1000
Cityliner N116 ▼ (75-99)	700	700
Cityliner N116-▲ (02/86-)	800	800
Cityliner N122/2 ▲ (02/86-)	800	800
Cityliner N122/2 ▲ (08/83-01/86)	700	700
Euroliner N3316 SHD / N3316 K	1000	1000
Euroliner N313SHD / N3316 UL	1000	1000
Jumbocruiser ▲ (02/86-)	800	800
Jumbocruiser ▲ (08/83-01/86)	700	700
Megaliner N128/4 ▼	700	700
Megaliner N128/4 ▲	800	800
Megaliner N128/4 Megaspacer ▼	700	700
Megaliner N128/4 Megaspacer ▲	800	800
Metroliner N8008, 8012 MIC (92-)	1000	1000
Skyliner N122/3 ▼ (02/86-)	700	700
Skyliner N122/3 ▲ (02/86-)	800	800
Skyliner N122/3 P, N122/3 L, N122-▼ (02/86-)	700	700
Skyliner N122/3 P, N122/3 L, N122-▲ (02/86-)	800	800
Spaceliner N117/2 ▲ (02/86-)	800	800
Spaceliner N117/2 ▼ (08/82-)	700	700
Spaceliner N117/3 ▲ (02/86-)	800	800
Spaceliner N117/3 ▼ (08/82-)	700	700
Starliner 516-▼	800	800
Transliner N312 (91-)	1000	1000
Transliner N314 (91-)	1000	1000
Transliner N316 L/U/K/SHD (91-)	1000	1000
Transliner N318 (91-)	1000	1000
Transliner N321 U (91-)	1000	1000
Transliner N4008, N 4012, N 4017 MIC (89-)	1000	1000
Transliner N407 SKI (81-)	800	800
Transliner Unibus N 906, N907/Telebus (82-)	800	800
NISSAN	☞	☞
Atleon (00-)	600	550
Atleon (08-)	510	510
Eco-T 100 (09/96-)	510	510
Eco-T 135 (09/96-)	510	510
Eco-T 160 (09/96-)	510	510
Eco-T 200 (09/96-)	510	510
Kubistar (11/03-)	510	510
L 35	510	510
Trade (01/86-00)	510	510
Vanette (09/86-05/95)	510	510
Vanette Cargo (06/95-)	600	600
OBRADORS	☞	☞
St 5 C, St 400 ▲ (94-)	800	800
OMNIBUS	☞	☞
Sunset (Sprinter) (-05/06)	600	550
OPEL	☞	☞
Combo (10/01-)	510	
PEGASO	☞	☞
1080, 1083, 1086, 1135, 1145 (02/81-01/86)	510	510
1080, 1083, 1086, 1135, 1145 (02/87-)	510	510
1180, 1181, 1183, 1184, 1186 (01/87-)	510	510
1190, 1231, 2080, 2081, 2082 (01/87-)	510	510
1234R, 2217, 2323, 2331 (01/85-)	510	510
2180, 2181, 2182, 2189, 2190 (01/87-)	510	510
3080, 3180, 3181, 3188, 3189 (01/87-)	510	510
Serie 260 (01/90-)	510	510
Serie Mider (01/91-)	510	510
Serie Obras (01/91-)	510	510
Tecno 1223, 1231, 1234, 1331 (09/88-)	510	510
Tecno 2323, 2331 (09/88-)	510	510

PEUGEOT	☞	☞
Expert (10/95-12/06)	660	510
J5 (01/82-02/94)	510	510
Partner (01/97-10/02)	550	550
Partner (06/96-)	550	550
Partner (11/02-)	550	550
RENAULT TRUCKS (RV)	☞	☞
C 210 -- C 340 (01/75-05/87)	510	510
C 210 -- C 340 (06/87-)	510	510
CBH-Serie 280 (04/86-05/87)	510	510
CS, MS (Mack) (01/86-)	510	510
G (Maxter, Manager) (01/93-)	600	600
G 170 -- G 340 (01/83-12/92)	510	510
Gamme B (Messenger) (01/93-)	600	600
Gamme B 70, B 90 (01/83-12/92)	700	700
GB 131, GB 191, GB 231 (06/80-12/84)	510	510
GC 231 (80-12/85)	510	510
GR 191, GR 231, GR 305 (06/80-12/84)	510	510
GRH 235, GRH 305, GRH 350 (06/80-12/84)	510	510
J (06/87-)	600	600
Kangoo / Kangoo expr. (01/09-)	550	550
Kangoo / Kangoo expr. (07/01-12/07)	510	510
Kangoo 2 / Expr. / Compact (01/08-)	550	550
M 140 -- M 230 (Midliner) (01/87-)	600	600
Magnum AE 380 -- 520 (03/97-)	700	700
Magnum AE 380 -- 520 (10/90-02/97)	700	700
Master (03/89-10/97)	600	600
Master (09/80-02/89)	600	600
Maxity (08-)	510	510
R (Major) (01/81-)	510	510
S 90 -- S 220 (01/75-05/87)	510	510
S 90 -- S 220 (Midliner) (06/87-)	600	600
TB 191, TB 231 (06/80-12/84)	510	510
Trafic (04/89-03/01)	510	510
SCANIA	☞	☞
Irizar Century (04-)	1000	1000
Omnicity (09/96-)	800	800
Omniline IL94 IB (11/00-)	900	900
Omnilink (98-01)	800	800
P Serie 230 -- 420 (P, R, T) (04-08/05)	700	700
P Serie 230 -- 420 (P, R, T) (09/05-)	700	700
R Serie 230 -- 620 (P, R, T) (09/05-)	700	700
R Serie 380 -- 580 (P, R, T) (04-08/05)	700	700
Serie 111 L, LB, LS, LT, LBS, LBT, Super (01/75-01/81)	510	510
Serie 112 - A (CN) (84-)	700	700
Serie 116 (BR) (01/79-)	700	700
Serie 116 (CN) (84-)	700	700
Serie 140 L, LB, LS, LT, LBS, LBT, Super (01/77-01/81)	510	510
Serie 145 (BR) (01/71-01/81)	700	700
Serie 145 (CR) (08/71-01/81)	700	700
Serie 146 KT, LB, LT (01/76-01/81)	510	510
Serie 2 - 112 (CR) (01/78-)	700	700
Serie 2 - 112 M, H (P, R, T) (08/79-03/88)	600	600
Serie 2 - 142 L, LB, LS, LT, LBS, LBT, Super (01/75-01/81)	510	510
Serie 2 - 142 M (R, T) (08/79-03/88)	600	600
Serie 2 - 82 (G, P, T) (08/79-03/88)	600	600
Serie 2 - 92 M, 92 L, 92 LB, 92 LBS (01/81-01/88)	600	600
Serie 3 - 113 M, H, R (04/88-)	600	600
Serie 3 - 143 M, H (04/88-)	600	600
Serie 3 - 93 M, 93 H (04/88-)	600	600
Serie 4 - 114 C, G, L (10/95-)	700	700
Serie 4 - 124 C, G, L (10/95-)	700	700
Serie 4 - 144 C, G, L (10/95-)	700	700
Serie 4 - 164 C, G, L (05/00-)	700	700
Serie 4 - 94 C, D, G, L (10/95-)	700	700
Serie 81 (LB) (01/75-01/81)	510	510
Serie 85 (BR, CR, Super) (01/73-01/81)	700	700
Serie 85 L, LB, LS, LBS, LBT, Super (01/69-01/75)	510	510
Serie 86 L, LB, LS, LBS (01/75-01/81)	510	510
Serie G (08-)	700	700
T Serie 230 -- (P, R, T) (09/05-)	700	700
T Serie 380 -- 580 (P, R, T) (04-08/05)	700	700

SMIT	☞	☞
Mercurius (94-)	800	800
SOLARIS	☞	☞
Urbino III	800	800
STEYR	☞	☞
1291 > 1491 260, 280, 310, 320 (04/78-12/87)	510	510
13 S14, 17 S14, 18, 21, 23 (04/86-)	510	510
18 S36, 19 S36, 19 S42, 33 S42 (01/94-)	510	510
1891 280, 310, 320, 330 (02/82-12/87)	510	510
19 S24, 40 S37 (01/87-)	510	510
28 S36	510	510
2891 260, 280, 330 (10/83-12/87)	510	510
320, 360, 390 (01/87-)	510	510
35 S36	510	510
591, 691 (01/84-04/86)	510	510
791, 145, 170, 195, 210 (11/78-02/86)	510	510
8 S14, 8 S18 (04/89-)	510	510
891, 170 (11/78-02/86)	510	510
Citybus Sc 6 F 55/65 (01/75-)	700	700
Sg 18 Hua 250	700	700
Si 11 Hu 200, Si 11 Hua 250	700	700
Ss 11 Hu 200, Ss 11 Hua 250	700	700
Stadtbuss Cs 6 F 55 (10/73-)	700	700
Transitbusse (St.U.Ü)	700	700
TAM	☞	☞
122 A 75T (01/92-)	700	700
122 T 8B (01/92-)	600	600
260 A 116P (01/92-)	800	800
260 T 17BL (01/92-)	600	600
TERBERG	☞	☞
FM 1350	660	660
FM 1450	660	660
FM 1850	660	660
FM 1950	660	660
FM 2000	660	660
FM 2850	660	660
FM 3000	660	660
YT 182 (4x2) (08-)	800	
TITAN	☞	☞
TF 3000 (10x8)	600	600
TTR 340 (8x8)	510	510
VAN HOOL	☞	☞
EOS 100 ▼ (01/90-)	800	800
EOS 100 ▲ (01/90-)	800	800
EOS 200 ▼ (91-09/99)	800	800
EOS 200 ▲ (91-09/99)	600	600
EOS 230 ▼ (01/94-)	800	800
EOS 230 ▲ (01/94-)	600	600
EOS 233 ▼ (01/94-09/99)	800	800
EOS 233 ▲ (01/94-09/99)	600	600
T815 Acron (Royal/New Look) ▲ (88-)	510	510
T815 Alicron (Royal/New Look) ▲ (91-)	510	510
T 9 Actron ▲ (95-)	510	510
T 915 Actron ▲	510	510
T 916 / 917 Altano ▼ (99-)	800	800
T 916 / 917 Altano ▲ (99-)	800	800
T 918 Altano ▼	800	800
T 918 Altano ▲	800	800
TD 927 Astromega ▼ (97-)	800	800
TD 927 Astromega ▲ (97-)	800	800

VDL	☞	☞
Arrow 30	1000	1000
Arrow 70	1000	1000
Axial 100 ▼	800	800
Axial 100 ▲	660	660
Axial 70 ▲	660	660
Axial DD138-430XE (BOVA)	800	800
Kusters Mid Euro XL (05/95-05/06)	600	550
Mini Bus (MB 308) (-05/06)	600	550
Mistral 70 ▼	1000	1000
Mistral 70 ▲	660	660
Phileas	800	
VOLKSWAGEN	☞	☞
Bully (-12/83)	510	510
Caravelle, California (09/90-)	550	550
City-Bus (01/92-)	600	600
LT (09/96-06/06)	600	510
LT 28 -- LT 50 (12/82-08/96)	510	510
Transporter T4 (09/90-12/03)	550	550
Transporter T5 (11/03-)	600	550
VOLVO	☞	☞
9700 ▼	1000	1000
9900 ▼	1000	1000
B 12 M ▼	1000	1000
B 12 M ▲	660	660
F 10 (08/77-10/93)	600	600
F 12 (08/87-10/93)	600	600
F 16 (08/77-10/93)	600	600
F 4 (09/75-12/85)	600	600
F 6 (09/75-12/85)	600	600
F 7 (08/77-10/93)	600	600
FH 10 (02/06-)	660	660
FH 10 (11/93-01/06)	660	660
FH 12 (02/06-)	660	660
FH 12 (11/93-01/06)	660	660
FH 16 (02/06-)	660	660
FH 16 (11/93-01/06)	660	660
FL 10 (09/85-09/95)	700	700
FL 12 (10/95-97)	700	700
FL 220, FL 250 (09/00-11/06)	600	600
FL 4 (01/85-)	600	600
FL 6 (02/94-11/06)	600	600
FL 6 (09/85-12/94)	600	600
FL 7 (09/85-09/90)	700	700
FL 7 (10/95-98)	700	700
FM (02/06-)	660	660
FM 10 (06/98-12/01)	660	660
FM 12 (06/98-01/06)	660	660
FM 7 (06/98-12/01)	660	660
FM 9 (12/98-03)	660	660
FS 10 (01/85-09/95)	700	700
FS 7 (01/85-95)	600	600
CH 230	600	600
N 4 (01/85-)	600	600
NH 12 (09/00-)	660	660
NL 6 (01/75-)	600	600